



NOTES:

1. USE MODEL POLARA, PLAQUE, AND FRAME BDSP-014-B FOR PED PUSH BUTTON.
2. TWO W11-2 OR S1-1 CROSSING WARNING SIGNS (EACH WITH RRFB AND W16-7P PLAQUE) SHALL BE INSTALLED AT THE CROSSING, ONE ON THE RIGHT-HAND SIDE OF THE ROADWAY AND ONE ON THE LEFT-HAND SIDE OF THE ROADWAY. IF A MEDIAN EXISTS, THE LEFT-HAND SIDE ASSEMBLY SHOULD BE INSTALLED ON THE MEDIAN.
3. INSTALL RRFB WITH LED INDICATOR FOR PEDESTRIAN ON SIDE OF TRAVEL LANE.
4. SEE STANDARD DETAIL 417 FOR BANDING SPEC AND INSTALLATION.

Rob Crittenden
 APPROVED BY: ROB CRITTENDEN
 TRAFFIC OPERATIONS SAFETY AND ENGINEERING MANAGER
 REVISION DATE: MARCH 01, 2016



STANDARD DETAILS
 RECTANGULAR RAPID FLASHING BEACON
 FILE NAME: SD484.DWG DETAIL NUMBER: 484